

Siemens Alarm System





Safe Home SA

Rue de Genève 70 - 1004 Lausanne Tél: 0848 848 555 Fax: 0848 848 556

www.safehome.ch

To activate full surveillance Enter code and confirm with the

square black key.

Use the key card and confirm with the

square black key.

To activate partial surveillance Enter the code and confirm with the

black A or B keys.

Use the key card and confirm with the

black A or B keys.

To disable surveillance: Enter the code and confirm with the

empty square key.

Use the key card and confirm with the

empty square key.

If you enter the wrong code four consecutive times then further attempts will be prohibited for 1 minute.

Changing codes or key cards:

Enter the code and then press the right arrow. Select User Management from the menu. Add, Edit or Delete.

Note: Only Managers Users are authorised to do this.

Without the document entitled "customer data" and your key cards we cannot activate your security system.

Please send them by registered post in a padded envelope to the following address:

Protectas SA, Impasse Colombelle 8, 1218 Le Grand-Saconnex