



# Alarm system

## Safe Home CLI 810 HF.




### Alarming system «Total»

Press  button and enter your secret code, depending on programming mode.

The siren of the control panel emits **a lot of audibles signals** to confirm the function – only if it's programmed.

### Alarming system «Partial»

Press  button and enter your secret code, depending on programming mode.

The siren of the control panel emits **a lot of audibles signals** to confirm the function – only if it's programmed.

### Alarming system «Annexe»

Press  button and enter your secret code, depending on programming mode.

The siren of the control panel emits **a lot of audibles signals** to confirm the function – only if it's programmed.

### Disarming system «Total and Annexe»




Enter your secret code. (You can enter your code in a sequence of 20 numbers).


The siren of the control panel emits **one audible signal** to confirm the function.





### Changing code

 & 	Master code	User number (1 to 9)	New code (4 digits)	New code (4 digits)	Test to do by customer
Red indicator flashes				long beep	



### Adjust the audible beep level

 & 		8	Sound level 0 to 7
			0 = No sound 1 to 7 = siren of the control panel emits an audible signal





-  Alarming system «Total»
-  Disarming system
-  Alarming system «Partial»
-  5 sec: on wich mode is the alarm system

### SOS / Alert on the remote control

Press  &  button simultaneously to trigger an alert (silent alert).

### SOS / Alert on the panel control

Press  &  button simultaneously to trigger an alert (silent alert).



# SAFEHOME

Without the document «formular for customer» and your keys,  
**unfortunately we cannot activate your security system.**

Please send it **with a protected envelope** and per registered mail (LSI) to:  
Protectas SA, Impasse Colombelle 8 à 1218 Le Grand-Saconnex

Safe Home SA, rue de Genève 70, 1004 Lausanne  
tel. 0848 848 555 · fax 0848 848 556 · [www.safehome.ch](http://www.safehome.ch)